



Stand	Latitude	Longitude	INS CHECK POINTS		Conditions
			Max. Wingspan	Max. Length	
11A	52 41 44.65 N	008 55 14.79 W	73.30m	69.10m	TAXI IN, PUSH OUT. STAND 11B MUST BE VACANT.
11B	52 41 43.49 N	008 55 16.13 W	73.30m	69.10m	PUSH IN, TAXI OUT IF STAND 11C IS VACANT AT EXIT. TOW OUT IF STAND 11C IS OCCUPIED AT EXIT. STAND 11A MUST BE VACANT.
11C	52 41 46.44 N	008 55 12.73 W	73.30m	69.10m	PUSH IN, TOW OUT. STANDS 11A AND 11B MUST BE VACANT AT ENTRY AND EXIT.
21	52 41 36.90 N	008 54 59.28 W	28.50m	32.70m	SELF MANOEUVRING.
22	52 41 35.00 N	008 54 57.04 W	44.40m	46.70m	SELF MANOEUVRING. STAND 21 MUST BE VACANT AT ENTRY.
23	52 41 28.16 N	008 54 54.27 W	59.70m	70.40m	TAXI IN, PUSH OUT. THIS STAND MAY BE USED BY AIRCRAFT WITH WINGSPAN EXCEEDING 59.70m IF STANDS 24 AND 24A ARE VACANT.
24	52 41 28.97 N	008 54 57.46 W	45.30m	57.20m	TAXI IN, PUSH OUT. MAX WINGSPAN 59.70m ON STAND 23. STANDS 24A AND 24B MUST BE VACANT. STAND 25A MUST BE VACANT AT ENTRY AND EXIT.
24A	52 41 29.54 N	008 54 57.39 W	30.20m	36.50m	TAXI IN, PUSH OUT. MAX WINGSPAN 59.70m ON STAND 23. STAND 24 MUST BE VACANT.
24B	52 41 30.33 N	008 54 58.93 W	30.20m	36.50m	TAXI IN, PUSH OUT. STAND 24 MUST BE VACANT.
25	52 41 30.97 N	008 55 00.30 W	44.40m	46.70m	TAXI IN, PUSH OUT. STANDS 25A AND 25B MUST BE VACANT.
25A	52 41 31.13 N	008 55 00.48 W	30.20m	36.50m	TAXI IN, PUSH OUT. STAND 25 MUST BE VACANT.
25B	52 41 31.96 N	008 55 02.03 W	30.20m	36.50m	TAXI IN, PUSH OUT. STAND 25 MUST BE VACANT.
26A	52 41 32.66 N	008 55 03.70 W	28.90m	36.50m	TAXI IN, PUSH OUT.
26B	52 41 33.56 N	008 55 05.09 W	28.90m	36.50m	TAXI IN, PUSH OUT.
27*	52 41 34.49 N	008 55 06.69 W	34.40m	46.70m	TAXI IN, PUSH OUT.
28*	52 41 36.39 N	008 55 08.33 W	44.00m	46.70m	TAXI IN, PUSH OUT.
30	52 41 36.54 N	008 55 10.56 W	60.30m	58.40m	TAXI IN, PUSH OUT.
32	52 41 36.62 N	008 55 14.22 W	60.30m	70.40m	TAXI IN, PUSH OUT.
34	52 41 36.87 N	008 55 18.28 W	65.00m	70.40m	TAXI IN, PUSH OUT.
37	52 41 36.97 N	008 55 22.34 W	65.00m	70.40m	TAXI IN, PUSH OUT.
39	52 41 37.51 N	008 55 26.26 W	65.00m	70.40m	TAXI IN, PUSH OUT.
41	52 41 37.85 N	008 55 29.70 W	45.30m	57.20m	TAXI IN, PUSH OUT. STAND 42 MUST BE VACANT.
42	52 41 37.60 N	008 55 31.17 W	73.30m	70.40m	TAXI IN, PUSH OUT. STANDS 41 AND 43 MUST BE VACANT.
43	52 41 37.90 N	008 55 32.09 W	29.00m	62.70m	TAXI IN, PUSH OUT. STAND 42 MUST BE VACANT.

NOTE 1 : * DATA WHOSE ACCURACY HAS NOT BEEN QUALITY ASSURED.

NOTE 2 : RESPONSIBILITY FOR CONTROL OF SURFACE TRAFFIC ON THE : -
 APRON - RESTS WITH THE AIRPORT AUTHORITY.
 MANOEUVRING AREA - RESTS WITH THE AIR TRAFFIC SERVICES.

CHANGES : CHANGE OF MAGNETIC VARIATION.